

Concave Batten Caps

**For Laser 4.7, Radial and Standard MKI (Cross Cut) Sails
Not applicable for Standard MKII (Bi-Radial Cut) Sails**

The diagrams below illustrate the methods to be used for the measurement of battens using both classic and concave end caps. Please see pages 39-42 for full sail and bottom section diagrams.

